

INSTALLATION INSTRUCTIONS

PODSZUCK

B-CLASS HINGED SINGLE DOORS

1. Check that the size of the panel opening is correct, see drawing for the door.
2. Check that the panel is straight and at right angles.
3. Check that the angles of the frame are at 90 ° to one another.
4. Install the frame from one side and the counter-frame from the other side.
5. Press the panel between frame and the counterframe with fixing clips on the hinge side.
6. Drill and install the four screws on the hinge side.
7. Fix the door itself and then check the gaps and angles.
8. If the gaps and angles are correct, then repeat steps 5 and 6.
9. Make a final check by closing and opening the door.
10. Install any handles and other fittings onto the door.